



FUNI METALLICHE
Informazioni utili per l'uso
delle funi metalliche



STEEL WIRE ROPES
Basic information required
to safely use wire rope

- Mai usare funi danneggiate o sottoposte a riparazione;
- L'impiego sbagliato, scorretto ed eccessivo accelerano la riduzione della vita lavorativa della fune;
- Il carico di rottura minimo (C.R.) è inteso per funi nuove o inutilizzate;
- Considerare attentamente e correttamente il coefficiente di sicurezza in base all'impiego;
- Non sovraccaricare mai la fune;
- Fare ispezionare periodicamente lo stato delle fune da una persona qualificata. **IN CASO DI DUBBIO SOSTITUIRE LA FUNE;**
- Evitare il sollevamento "a strappo";
- Considerare correttamente l'indice di rendimento o coefficiente di riduzione degli attacchi delle funi metalliche;
- Per ulteriori informazione ed informazione più specifiche come criteri di verifica della fune metallica, indici di sostituzione della fune, lubrificazione, movimentazione e stoccaggio delle fune ed altro, vi rimandiamo al nostro manuale "USO E MANUTENZIONE DELLE FUNI METALLICHE" disponibile presso la nostra home page: www.italmet.com oppure inviandoci una mail al customercare@italmet.com.

- Wire rope will fail if worn-out, overloaded, misused, damaged, or improperly maintained;
- Abuse and misuse increase the rate of loss;
- The MBL of rope is mean only to a new rope;
- To determinate the SWL or WLL of a wire rope the MBL must be reduced by design factor or safety factor depending upon finally applications;
- Never overload a wire rope;
- Wire rope must be periodically and regularly inspected and keeping of permanent records by professional workers. **IF IN DOUBT REPLACE THE ROPE;**
- Never shock load-up a wire rope;
- Every rope user should be aware of the fact that each type of fitting attached to a wire rope has a specific efficiency rating wich can be reduce the WLL;
- Further informations for inspections, maintenance, inspections, lubrications and more are contained on "USO E MANUTENZIONI" download trough our web site: www.italmet.com or mail at customercare@italmet.com.

